

# LOCK ● A ● MATIC NO. 900 BED CANOPY FRAME

**1** Assemble one half section of canopy frame at a time.  
(Dotted line separates two halves.)

**2** Insert cross rods into slots of curved pieces as indicated.  
(SEAMS UP)

**3** To lock cross rods in place, grip curved pieces at point of arrows and rotate until slots are facing up. Note diagram of assembled half section.

**4** Connect assembled half sections together.

**5** Place end pieces into position with curved pieces locking over ends.

**6** Position bed post finials into each of the large holes at the four corners of the frame. With the help of another person, pick up frame and place on bed.

